Welcome to HTC

htc MAGIC

Quick Start Guide

For a more complete guide in using your phone,
download the User Manual PDF from www.htc.com

Please Read Before Proceeding

THE BATTERY IS NOT CHARGED WHEN YOU TAKE IT OUT OF THE BOX.

DO NOT REMOVE THE BATTERY PACK WHEN THE PHONE IS CHARGING.

YOUR WARRANTY IS INVALIDATED IF YOU DISASSEMBLE OR ATTEMPT TO DISASSEMBLE THE DEVICE.

PRIVACY RESTRICTIONS

Some countries require full disclosure of recorded telephone conversations, and stipulate that you must inform the person with whom you are speaking that the conversation is being recorded. Always obey the relevant laws and regulations of your country when using the recording feature of your phone.

Limitation of Damages

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL HTC OR ITS PROVIDERS BE LIABLE TO USER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, INCIDENTAL OR PUNITIVE DAMAGES OF ANY KIND, IN CONTRACT OR TORT, INCLUDING, BUT NOT LIMITED TO, INJURY, LOSS OF REVENUE, LOSS OF GOODWILL, LOSS OF BUSINESS OPPORTUNITY, LOSS OF DATA, AND/OR LOSS OF PROFITS ARISING OUT OF, OR RELATED TO, IN ANY MANNER, OR THE DELIVERY, PERFORMANCE OR NONPERFORMANCE OF OBLIGATIONS, OR USE OF THE WEATHER INFORMATION, DATA OR DOCUMENTATION HEREUNDER REGARDLESS OF THE FORESEEABILITY THEREOF.

*** IMPORTANT REMINDER ***

Most applications on the phone need a constant Internet connection. **It is strongly recommended** that you subscribe to a flat-rate data plan from your wireless service provider. If you do not have a flat-rate data plan, you may incur significant data connection charges when the phone accesses the Internet. We strongly advise you to check with your wireless service provider for the data rates first before you use the phone.

Congratulations on your purchase of the **HTC Magic**.

This **Quick Start Guide** will help you get started with your Android™-powered phone. For a more complete guide in using the phone, download the User Manual PDF.

Contents

1. Inside the Box 4
2. Your HTC Magic 4
3. Before You Turn On Your Phone 5
4. Get Started 7
5. HTC Sense™ 8
6. Get Your Contacts into the Phone 11
7. Get On the Internet 12
8. Get Your Messages Across 14
9. Social Networking 15
10. Get Files into Your Phone 16
11. Reset the Phone 17
12. Troubleshooting 18

1. Inside the Box

You should find the following items inside the box.

- HTC Magic phone
- USB cable
- Wired stereo headset
- microSD™ card
- Pouch
- Battery
- AC adapter
- This Quick Start Guide

2. Your HTC Magic



3. Before You Turn On Your Phone

1

Remove the back cover

Hold the device securely with the front facing down, and then push the back cover down with your thumb until it disengages from the phone.



2

Install the SIM card

Locate the SIM card slot, and then insert the SIM card with its gold contacts facing down and its cut-off corner facing out the card slot. Slide the SIM card completely into the slot.



3

Install the battery

1. Align the battery's exposed copper contacts with the connectors inside the battery compartment.
2. Insert the contact side of the battery first then gently push the battery into place.



4

Install the microSD card

1. Insert the microSD card into the slot with its gold contacts facing down.
2. Press the microSD card all the way in until you hear a click.



5

Replace the back cover

1. Align the back cover tabs with the holes at both sides of the phone's exposed back panel.
2. Slide the back cover up until it clicks into place.



6

Charge the battery

1. Plug the USB connector of the AC adapter to the USB connector at the bottom of your phone.
2. Plug in the AC adapter to an electrical outlet to start charging the battery.



The battery is fully charged after about 3 hours of charging.

After doing these steps, you are now ready to turn on your phone for the first time. Read on and learn what you can do with your phone.

Press the END CALL/POWER button on the phone to turn it on.

4. Get Started

When you turn on your phone for the first time, you will be given options to let you quickly set up various accounts such as Google™ Account, Facebook™, Twitter™, Flickr®, Microsoft® Exchange ActiveSync®, and other email accounts.

You do not need to set up all the accounts to use the phone. However, if you do have those accounts, we suggest that you go ahead and set them up to take advantage of all the phone features.

Note You need an Internet connection to set up accounts.

1. Choose the language you want to use and then tap **Next**.
2. You may be asked to determine some options, view tutorials, or set up a Wi-Fi connection in the following screens. Tap **Next** or **Skip** to go to the following screen.

   Note You will only be asked to set up a Wi-Fi connection if there is a Wi-Fi connection available.

3. In the Set up accounts screen, choose which accounts you want to set up.
   After setting up an account, you will be taken back to the Set up accounts screen. Tap **Next** when you are done setting up the accounts.
4. In the Set up social network accounts screen, choose which social network accounts you want to set up.

After setting up an account, you will be taken back to the Set up social network accounts screen. Tap **Next** when you are done setting up the accounts.

5. On the Location consent screen, select the check box to allow Google's location service to collect location data, and then tap **Next**.

Note Some applications on your phone, such as World Clock and Weather, require Google's location service to automatically update the time and weather information for your current location.

6. Tap **Finish** to finish the setup process and go to the Home screen.

5. HTC Sense™

Discover HTC enhancements that make the phone just right for you, help you stay in touch and leave you delighted with their ease of use.

Home screen

The Home screen gives you a lot of real estate to work with so you can add the items you want and need on the Home screen.

Slide your finger from right to left or left to right to go to the extended Home screen.

Tip While in any application, press HOME to display the Home screen.

The Home screen extends beyond the screen width to provide more space for you to add items. There are 6 "additional" screens apart from the main Home screen.

HTC widgets

Personalize your Home screen by adding HTC widgets to it. Choose from Music, People, Twitter, and a host of other widgets, and arrange them in multiple profiles so that your phone molds perfectly to fit your life.

To add HTC widgets to the Home screen, press and then select **HTC widgets**.

Can't decide how to set up your Home screen? Check out **Scenes** that we've included in the phone. Scenes are preset Home screen layouts that you can quickly apply. On the Home screen, press MENU and then tap **Scenes** to check out the presets.

Scenes

Looking to make a scene? You can customize your Home screen and then save it as a scene.

1. Customize the Home screen by changing the wallpaper and adding widgets.
2. After you are done customizing, press MENU and then tap **Scenes**.
3. Select **Current (unsaved)** and then tap **Save**.
4. Enter the **Scene name** and then tap **Done**.

Tip You can rename or delete a custom scene in the Settings screen. On the Settings screen, tap **Personalize** > **Scenes**, and then press and hold a custom scene.

Onscreen keyboard

When you start a program or select a field that requires text or numbers, the onscreen keyboard becomes available. You can choose from three onscreen keyboard layouts: **QWERTY**, **Compact QWERTY**, and **Phone keypad**.



The onscreen keyboard offers word prediction and spell correction features helping you type faster and more accurately.

An example of an onscreen keyboard: QWERTY

Smart Dial

Dial the way you think. The **Smart Dial** feature searches for contact phone numbers and the first character of a contact name as well as from the character that appears after a space, dash, or underscore in a contact name. Whether you're dialing by name or number, Smart Dial gets it right.



People

Bring the people who matter the most closer. All your text exchanges, email conversations, Facebook status, Flickr photo albums and phone logs are neatly organized by your contacts.

Tap a contact in the list to view all communications between you and that person.



6. Get Your Contacts into the Phone

Keep tabs on your people with People. All your communications with a contact are nearly arranged for easy viewing.

On the Home screen, tap , and then tap **People**.

Importing all contacts from your SIM card

On the All tab, press MENU, and then tap **Import**.

Note If you have a Google or Exchange ActiveSync account set up on your phone, choose the type for the imported contacts, and then tap **OK**.

Adding a new contact using the phone

1. On the All tab, tap **Add contact**.
2. Tap the Name field, enter the first and last name of the contact, and choose the order in which to display the names.
3. Tap to hide the onscreen keyboard, and then tap **OK**.

4. Enter the contact information in the fields provided.
5. Scroll to the bottom of the screen and tap **Save**.

Synchronizing Google, Exchange ActiveSync and Outlook contacts

If you have a Google Account, Microsoft Office Outlook, Windows Address Book (Outlook Express), or an Exchange ActiveSync account, you can synchronize the contacts in those accounts with your phone.

Refer to the User Manual PDF to learn how to synchronize contacts from these accounts.

7. Get On the Internet

Connect to the world through a data connection or Wi-Fi connection. Browse the web, download applications or games from Android Market, and send/receive emails.

Using a data connection

Your phone will be automatically configured to use your wireless service provider's GPRS/3G/EDGE service when you turn on your phone (if the SIM card is inserted) for the first time.

If your phone is not connecting, check the mobile network the phone is using and if data connection is turned on.

To check the mobile network the phone is using

1. Press HOME > MENU and then tap **Settings**.
2. Tap **Wireless controls > Mobile network settings > Network operators** or **Access Point Names**.

Turn on data connection by selecting the **Mobile network** check box in **Settings > Wireless controls**.

Using Wi-Fi

1. On the Home screen, press MENU and then tap **Settings > Wireless controls**.
2. Select the **Wi-Fi** check box to turn Wi-Fi on. The phone will scan for available wireless networks.
3. Tap **Wi-Fi settings**. The network names and security settings (Open network or Secured with WEP) of detected Wi-Fi networks are displayed in the Wi-Fi networks section.
4. Tap a Wi-Fi network to connect. If you selected an open network, you will be automatically connected to the network. If you selected a network that is secured with WEP, enter the key and then tap **Connect**.

Browsing the web

Experience rich Internet browsing with Browser's Flash player, visual bookmarks, and pinch zoom controls.

1. On the Home screen, tap **Browser**.
2. On the Browser screen, press MENU and then tap the URL field on top of the screen.
3. Enter the web page address using the keyboard. As you enter the address, matching web page addresses will appear on the screen. Tap an address to go directly to that web page or continue entering the web page address.
4. Tap **Go**. On the webpage, use finger gestures to browse the webpage or to zoom in or out.

Use your thumb and index fingers to 'spread' the web page to zoom in.

Use your thumb and index fingers to 'pinch' the web page to zoom out.

8. Get Your Messages Across

Set up multiple email inboxes ranging from personal accounts to Enterprise Exchange solutions. Enjoy multiple viewing options by conversation threads, flags or attachment.

To add a POP3/IMAP email account

1. On the Home screen, tap , and then tap **Mail**.
2. On the **Choose a mail provider** screen, tap the type of email account you want to set up. If you do not see the email account type you want on the screen, tap **Other (POP3/IMAP)**.

   Note If the account type you want to set up is not in the phone database, you will be asked to enter more details. It is recommended that you get all pertinent information for the email account such as incoming/outgoing server settings before you proceed.

3. Enter the **Email address** and **Password** for the email account and then tap **Next**.

4. Enter the **Account name** and **Your name** and then tap **Finish setup**.

To send emails

1. On the Home screen, tap , and then tap **Mail**.
2. On the email account Inbox, press MENU and then tap **Compose**.
3. Enter the message recipient's email address in the **To** field. As you enter information, matching contacts will appear on the screen. Tap the recipient or continue entering the email address. If you are sending the email to several recipients, separate the email addresses with a comma. You can add as many message recipients as you want.
4. Enter the subject, and then compose your message. Tap **Send**.

If you want to set up an Exchange ActiveSync account, refer to Chapter 5 of the User Manual PDF to learn how.

9. Social Networking

Stay in the loop with your friends with the social networking features. Update your status and get updates on events, photos, and status of your friends on Facebook™, view photos on Flickr®, and follow your tweets on Twitter.

The People application is tightly integrated with Facebook and Flickr, letting you know if your friends have updates on their accounts.




2:58 AM
All tweets
What are you doing?
23/11/2009
2:58 AM
clairenichols1 I'm getting an HTC phone on Black Friday!
0min ago from web
TUbiEW927 @john888869, want a $50 Taco Bell gift card? Go here and get one!! http://is.gd/4XKdM
0min ago from API
john888869 Deja vu
2mins ago from HTC Peep
engadget OCZ's Colossus desktop SSD gets reviewed: oh yeah, it's fast http://bit.ly/5Edo0s
1hr ago from twitterfeed

Refer to Chapter 3 and 9 of the User Manual PDF to learn more about People and Peep (the Twitter client on the phone).

10. Get Files into Your Phone

Bring your files with you. With the phone's wide range of file support, you can view Word, Excel, PowerPoint, and PDF files, listen to music, and smile at those precious photos and videos on your phone.

Note You need to have a microSD card installed to copy files into the phone.

1. Connect the phone to the computer using the USB cable. A notification icon appears in the status bar.
2. Open the Notifications panel (by touching and then dragging the status bar down).
3. In the Notifications panel, tap **USB connected,** and then tap **Mount**.

Note When the phone is mounted, you will not be able to use some of the phone's applications such as Camera. You need to turn off USB storage for the phone to recognize the storage card when the phone is connected to a computer. Refer to the User Manual for details.

4. On your computer, navigate to the USB drive of the phone and open it.
5. Copy the files into the phone's storage card.

11. Reset the Phone

Need to start over? Resetting the phone deletes all data, including downloaded applications, and resets the phone back to its initial state—the state before you turned on the phone for the first time.

Important Make sure to back up important data you have on the phone before you reset the phone.

To reset the phone

1. On the Home screen, press MENU, and then tap **Settings > SD card & phone storage > Factory data reset**.
2. On the Factory data reset screen, tap **Reset phone** and then tap **Erase everything**.

To reset the phone using phone buttons

1. With the phone turned off, press and hold the HOME and BACK buttons, and then briefly press the END CALL/POWER button. The reset process will start after a few seconds.
2. Wait for the phone to finish the reset process and then press MENU.

12. Troubleshooting

Here are some things you can do when your phone hangs, has problems running applications, or is operating slowly:

- Check if there is enough free space on the phone to run the application.
  To check free space, press HOME > MENU, and then tap **Settings > SD card & phone storage**.
- Clear data and cache of applications.
  To clear data and cache, press HOME > MENU, and then tap **Settings > Applications > Manage applications**.
- Uninstall third-party applications.
  To uninstall third-party applications, press HOME > MENU, and then tap **Settings > Applications > Manage applications**.
- If your phone is not responding to input, remove the battery, wait for 3 seconds, then reinsert the battery and turn on the phone.
- Backup important phone data and then reset the phone.
  To reset the phone, press HOME > MENU, and then tap **Settings > SD card & phone storage > Factory data reset**.
- Check for updates and useful tips on the HTC website - www.htc.com.

Intellectual Property Right Information

Copyright © 2010 Google Inc. Used with permission.

Google, the Google logo, Android, Google Search, Google Maps, Gmail, YouTube, Android Market, and Google Talk are trademarks of Google Inc.

Google, the Google logo and Google Maps are trademarks of Google, Inc. TeleAtlas® Map Data ©2010. Street View Images ©2010 Google.

Important Health Information and Safety Precautions

When using this product, the safety precautions below must be taken to avoid possible legal liabilities and damages.

Retain and follow all product safety and operating instructions. Observe all warnings in the operating instructions on the product.

To reduce the risk of bodily injury, electric shock, fire, and damage to the equipment, observe the following precautions.

ELECTRICAL SAFETY

This product is intended for use when supplied with power from the designated battery or power supply unit. Other usage may be dangerous and will invalidate any approval given to this product.

SAFETY PRECAUTIONS FOR PROPER GROUNDING INSTALLATION

CAUTION: Connecting to an improperly grounded equipment can result in an electric shock to your phone.

This product equipped with a USB Cable for connecting with desktop or notebook computer. Be sure your computer is properly grounded (earthed) before connecting this product to the computer. The power supply cord of a desktop or notebook computer has an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet which is properly installed and grounded in accordance with all local codes and ordinances.

SAFETY PRECAUTIONS FOR POWER SUPPLY UNIT

- **Use the correct external power source**
  A product should be operated only from the type of power source indicated on the electrical ratings label. If you are not sure of the type of power source required, consult your authorized service provider or local power company. For a product that operates from battery power or other sources, refer to the operating instructions that are included with the product.
  This product should be operated only with the following designated power supply unit(s):
  AC Adapter
  - Phihong, Models PSAA05A-050, PSAA05C-050, PSAA05E-050, PSAA05K-050 and PSAA05S-050.
  - HTC, Model TC P300

  Car Adapter
  - Phihong, Model CLA05D-050
- **Handle battery packs carefully**
  This product contains a Li-ion battery. There is a risk of fire and burns if the battery pack is handled improperly. Do not attempt to open or service the battery pack. Do not disassemble, crush, puncture, short external contacts or circuits, dispose of in fire or water, or expose a battery pack to temperatures higher than 60˚C (140˚F).

WARNING: Danger of explosion if battery is incorrectly replaced. To reduce risk of fire or burns, do not disassemble, crush, puncture, short external contacts, expose to temperature above 60° C (140° F), or dispose of in fire or water. Replace only with specified batteries. Recycle or dispose of used batteries according to the local regulations or reference guide supplied with your product.

Note This product should be operated only with the following designated Battery Pack(s).
- HTC, Model SAPP160

Take extra precautions

- Keep the battery or phone dry and away from water or any liquid as it may cause a short circuit.
- Keep metal objects away so they don't come in contact with the battery or its connectors as it may lead to short circuit during operation.
- The phone should be only connected to products that bear the USB-IF logo or have completed the USB-IF compliance program.
- Do not use a battery that appears damaged, deformed, or discolored, or the one that has any rust on its casing, overheats, or emits a foul odor.
- Always keep the battery out of the reach of babies and small children, to avoid swallowing of the battery. Consult the doctor immediately if the battery is swallowed.
- If the battery leaks:
  - Do not allow the leaking fluid to come in contact with skin or clothing. If already in contact, flush the affected area immediately with clean water and seek medical advice.
  - Do not allow the leaking fluid to come in contact with eyes. If already in contact, DO NOT rub; rinse with clean water immediately and seek medical advice.
  - Take extra precautions to keep a leaking battery away from fire as there is a danger of ignition or explosion.

SAFETY PRECAUTIONS FOR DIRECT SUNLIGHT

Keep this product away from excessive moisture and extreme temperatures. Do not leave the product or its battery inside a vehicle or in places where the temperature may exceed 60°C (140°F), such as on a car dashboard, window sill, or behind a glass that is exposed to direct sunlight or strong ultraviolet light for extended periods of time. This may damage the product, overheat the battery, or pose a risk to the vehicle.

PREVENTION OF HEARING LOSS

CAUTION: Permanent hearing loss may occur if earphones or headphones are used at high volume for prolonged periods of time.

Note For France, Earphone (listed below) for this device have been tested to comply with the Sound Pressure Level requirement laid down in the applicable NF EN 50332-1:2000 and/or NF EN 50332-2:2003 standards as required by French Article L. 5232-1.

- Earphone, manufactured by HTC, Model HS S300.

SAFETY IN AIRCRAFT

Due to the possible interference caused by this product to an aircraft's navigation system and its communications network, using this phone's phone function on board an airplane is against the law in most countries. If you want to use this phone when on board an aircraft, remember to turn off your phone by switching to Airplane Mode.

ENVIRONMENT RESTRICTIONS

Do not use this product in gas stations, fuel depots, chemical plants or where blasting operations are in progress, or in potentially explosive atmospheres such as fuelling areas, fuel storehouses, below deck on boats, chemical plants, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles, such as grain, dust, or metal powders. Please be aware that sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

EXPLOSIVE ATMOSPHERES

When in any area with a potentially explosive atmosphere or where flammable materials exist, the product should be turned off and the user should obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Users are advised not to use the equipment at refueling points such as service or gas stations, and are reminded of the need to observe restrictions on the use of radio equipment in fuel depots, chemical plants, or where blasting operations are in progress.

Areas with a potentially explosive atmosphere are often, but not always, clearly marked. These include fueling areas, below deck on boats, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

ROAD SAFETY

Vehicle drivers in motion are not permitted to use telephony services with handheld devices, except in the case of emergency. In some countries, using hands-free devices as an alternative is allowed.

SAFETY PRECAUTIONS FOR RF EXPOSURE

- Avoid using your phone near metal structures (for example, the steel frame of a building).
- Avoid using your phone near strong electromagnetic sources, such as microwave ovens, sound speakers, TV and radio.
- Use only original manufacturer-approved accessories, or accessories that do not contain any metal.
- Use of non-original manufacturer-approved accessories may violate your local RF exposure guidelines and should be avoided.

Exposure to Radio Frequency (RF) Signals

Your phone contains a radio transmitter and receiver. The radiated output power is far below the international radio frequency exposure limits. These limits are part of comprehensive guidelines and establish permitted levels of Radio Frequency energy for the general population. The guidelines are based on the safety standards previously set by international standards bodies:

- American National Standards Institute (ANSI) IEEE. C95.1-1992
- National Council on Radiation Protection and Measurement (NCRP). Report 86. 1986
- International Commission on Non-Ionising Radiation Protection (ICNIRP) 1996
- Ministry of Health (Canada), Safety Code 6. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in usage.

As with other mobile radio transmitting equipment, users are advised that for satisfactory operation of the equipment and for the safety of personnel, it is recommended that no part of the human body be allowed to come too close to the antenna during operation of the equipment.

Your phone has an internal antenna. Use only the supplied integral antenna. Use of unauthorized or modified antennas may impair call quality and damage your phone, causing loss of performance and SAR levels exceeding the recommended limits as well as result in non-compliance with local regulatory requirements in your country.

To assure optimal phone performance and ensure human exposure to Radio Frequency energy is within the guidelines set forth in the relevant standards; always use your phone only in its normal-use position. Do not touch or hold the antenna area unnecessarily when placing or receiving a phone call. Contact with the antenna area may impair call quality and cause your phone to operate at a higher power level than needed. Avoiding contact with the antenna area when your phone is IN USE optimizes the antenna performance and the battery life.

Tests for SAR are conducted using standard operating positions specified by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operation can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (for example, at the ear and worn on the body) as required by the FCC for each model. (Bodyworn measurements may differ among phone models, depending upon available accessories

and FCC requirements). For body worn operation, to maintain compliance with FCC RF exposure guidelines, use only original manufacturer approved accessories.

SAR Information

1.57 W/Kg @1g (Head)
1.22 W/Kg @1g (Body)

Limiting exposure to radio frequency (RF) fields

For individuals concerned about limiting their exposure to RF fields, the World Health Organisation (WHO) provides the following advice:

Precautionary measures: Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If individuals are concerned, they might choose to limit their own or their children's RF exposure by limiting the length of calls, or using 'hands-free' devices to keep mobile phones away from the head and body.

Further information on this subject can be obtained from the WHO home page at http://www.who.int/mediacentre/factsheets/fs193/en/.

INTERFERENCE WITH MEDICAL EQUIPMENT FUNCTIONS

This product may cause medical equipment to malfunction. The use of this device is forbidden in most hospitals and medical clinics.

If you use any other personal medical device, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.

Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

INTERFERENCE IN CARS

Please note that because of possible interference to electronic equipment, some vehicle manufacturers forbid the use of mobile phone in their vehicles unless a handsfree kit with an external antenna is included in the installation.

HEARING AIDS

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your service provider, or call the customer service line to discuss alternatives.

NONIONIZING RADIATION

Your device has an internal antenna. This product should be operated in its normal-use position to ensure the radiative performance and safety of the interference.

As with other mobile radio transmitting equipment, users are advised that for satisfactory operation of the equipment and for the safety of personnel, it is recommended that no part of the human body be allowed to come too close to the antenna during operation of the equipment.

Use only the supplied integral antenna. Use of unauthorized or modified antennas may impair call quality and damage the phone, causing loss of performance and SAR levels exceeding the recommended limits as well as result in non-compliance with local regulatory requirements in your country.

To assure optimal phone performance and ensure human exposure to RF energy is within the guidelines set forth in the relevant standards, always use your device only in its normal-use position. Contact with the antenna area may impair call quality and cause your device to operate at a higher power level than needed. Avoiding contact with the antenna area when the phone is IN USE optimizes the antenna performance and the battery life.



Electrical Safety

- Accessories
  - Use only approved accessories.
  - Do not connect with incompatible products or accessories.
  - Take care not to touch or allow metal objects, such as coins or key rings, to contact or short-circuit the battery terminals.
- Connection to a Car
  Seek professional advice when connecting a phone interface to the vehicle electrical system.
- Faulty and Damaged Products
  - Do not attempt to disassemble the phone or its accessory.
  - Only qualified personnel must service or repair the phone or its accessory.

General Precautions

You alone are responsible for how you use your phone and any consequences of its use. You must always switch off your phone wherever the use of a phone is prohibited. Use of your phone is subject to safety measures designed to protect users and their environment.

- **Avoid applying excessive pressure to the device**
  Do not apply excessive pressure on the screen and the device to prevent damaging them and remove the device from your pants' pocket before sitting down. It is also recommended that you store the device in a protective case and only use your finger when interacting with the touch screen. Cracked display screens due to improper handling are not covered by the warranty.
- **Device getting warm after prolonged use**
  When using your device for prolonged periods of time, such as when you're talking on the phone, charging the battery or browsing the web, the device may become warm. In most cases, this condition is normal and therefore should not be interpreted as a problem with the device.
- **Heed service markings**
  Except as explained elsewhere in the Operating or Service documentation, do not service any product yourself. Service needed on components inside the device should be done by an authorized service technician or provider.

- **Protect your phone**
  - Always treat your phone and its accessories with care and keep them in a clean and dust-free place.
  - Do not expose your phone or its accessories to open flames or lit tobacco products.
  - Do not drop, throw or try to bend your phone or its accessories.
  - Do not expose your phone or its accessories to liquid, moisture or high humidity.
  - Do not paint your phone or its accessories.
  - Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.
  - Do not attempt to disassemble your phone or its accessories, only authorized personnel must do so.
  - Do not expose your phone or its accessories to extreme temperatures, minimum –20 and maximum 55 degrees Celsius.
  - Please check local regulations for disposal of electronic products.
  - Do not carry your phone in your back pocket as it could break when you sit down.
- **Damage requiring service**
  Unplug the product from the electrical outlet and refer servicing to an authorized service technician or provider under the following conditions:
  - Liquid has been spilled or an object has fallen into the product.
  - The product has been exposed to rain or water.
  - The product has been dropped or damaged.
  - There are noticeable signs of overheating.
  - The product does not operate normally when you follow the operating instructions.
- **Avoid hot areas**
  The product should be placed away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.
- **Avoid wet areas**
  Never use the product in a wet location.

- **Avoid using your device after a dramatic change in temperature**
  When you move your device between environments with very different temperature and/or humidity ranges, condensation may form on or within the device. To avoid damaging the device, allow sufficient time for the moisture to evaporate before using the device.

NOTICE: When taking the device from low-temperature conditions into a warmer environment or from high-temperature conditions into a cooler environment, allow the device to acclimate to room temperature before turning on power.

- **Avoid pushing objects into product**
  Never push objects of any kind into cabinet slots or other openings in the product. Slots and openings are provided for ventilation. These openings must not be blocked or covered.
- **Air Bags**
  Do not place a phone in the area over an air bag or in the air bag deployment area. Store the phone safely before driving your vehicle.
- **Mounting accessories**
  Do not use the product on an unstable table, cart, stand, tripod, or bracket. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.
- **Avoid unstable mounting**
  Do not place the product with an unstable base.
- **Use product with approved equipment**
  This product should be used only with personal computers and options identified as suitable for use with your equipment.
- **Adjust the volume**
  Turn down the volume before using headphones or other audio devices.
- **Cleaning**
  Unplug the product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning, but NEVER use water to clean the LCD screen.

- **Small Children**
  Do not leave your phone and its accessories within the reach of small children or allow them to play with it. They could hurt themselves or others, or could accidentally damage the phone. Your phone contains small parts with sharp edges that may cause an injury or which could become detached and create a choking hazard.
- **Repetitive Motion Injuries**
  To minimize the risk of RSI, when Texting or playing games with your phone:
  - Do not grip the phone too tightly.
  - Press the buttons lightly.
  - Make use of the special features in the handset which minimize the number of buttons which have to be pressed, such as message templates and predictive text.
  - Take lots of breaks to stretch and relax.
- **Bright Light**
  This phone is capable of producing flash of light or use as a torch, do not use it too close to the eyes.
- **Operating machinery**
  Full attention must be given to operating the machinery in order to reduce the risk of an accident.
- **Electrostatic discharge (ESD)**
  Do not touch the SIM card's metal connectors.
- **Seizures/Blackouts**
  This phone is capable of producing bright flashing lights.
- **Loud Noise**
  This phone is capable of producing loud noises which may damage your hearing.
- **Emergency Calls**
  This phone, like any wireless phone, operates using radio signals, which cannot guarantee connection in all conditions. Therefore, you must never rely solely on any wireless phone for emergency communications.

Regulatory Agency Identifications

For regulatory identification purposes, your product is assigned a model number of **SAPP500**.

To ensure continued reliable and safe operation of your device, use only the accessories listed below with your **SAPP500**.

The Battery Pack has been assigned a model number of **SAPP160**.

Note This product is intended for use with a certified Class 2 Limited Power Source, rated 5 Volts DC, maximum 1 Amp power supply unit.

Telecommunications & Internet Association (TIA) safety information

- **Pacemakers**
  The Health Industry Manufacturers Association recommends that a minimum separation of 15 cm (6 in) be maintained between a handheld wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research. Persons with pacemakers:
  - Should ALWAYS keep the phone more than 15 cm (6 in) from their pacemaker when the phone is turned ON.
  - Should not carry the phone in a breast pocket.
  - Should use the ear opposite the pacemaker to minimize the potential for interference. If you have any reason to suspect that interference is taking place, turn the phone OFF immediately.
- **Hearing Aids**
  Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your service provider, or call the customer service line to discuss alternatives.
- **Other Medical Devices**
  If you use any other personal medical device, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Turn the phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

WEEE Notice

The Directive on Waste Electrical and Electronic Equipment (WEEE), which entered into force as European law on 13th February 2003, resulted in a major change in the treatment of electrical equipment at end-of-life.

The purpose of this Directive is, as a first priority, the prevention of WEEE, and in addition, to promote the reuse, recycling and other forms of recovery of such wastes so as to reduce disposal.

The WEEE logo (shown at the left) on the product or on its box indicates that this product must not be disposed of or dumped with your other household waste. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling of such hazardous waste. Isolated collection and proper recovery of your electronic and electrical waste equipment at the time of disposal will allow us to help conserving natural resources. Moreover, proper recycling of the electronic and electrical waste equipment will ensure safety of human health and environment. For more information about electronic and electrical waste equipment disposal, recovery, and collection points, please contact your local city centre, household waste disposal service, shop from where you purchased the equipment, or manufacturer of the equipment.

RoHS Compliance

This product is in compliance with Directive 2002/95/EC of the European Parliament and of the Council of 27 January 2003, on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS) and its amendments.

www.htc.com

90H01304-06M Rev.A